



Steam with water droplets is forced into circular cyclonic motion by the top tangential inlet. Steam spirals downward toward the base of the unit as centrifugal force moves the droplets, and any solids, to the side walls. The water falls out and steam reverses up through the outlet tube.